QUICK REFERENCE

NEO 2100, 1100 and 1000 Topside Panels


Refer to Instruction Manual for additional details.



- 1. Press UP button to set desired temperature. If in a Menu mode, then the UP to navigate the screen up.
- 2. Press DOWN button to set desired temperature. If in a Menu mode, then the DOWN to navigate the screen down.
- **3.** Press **MENU** button to get into the Menu for setting. Use **UP** or **DOWN** button to navigate, press **MENU** button then **UP** or **DOWN** button to set your desire. Refer to your Instruction Manual for additional details.
- 4. Press RETURN button to activate or back to previous setting. Optional:
 - a. For NEO 2100, the RETURN button can be used for Blower or Jet 5 or Option.
 - **b.** For **NEO 1100**, the **RETURN** button can be used for Blower or Jet 3 or Option.
 - c. For NEO 1000, the RETURN button can be used for Blower or Jet 2 or Option.
- **5.** Press **LIGHT** button, the Spa Light turns **ON**, press **LIGHT** button again, the Spa Light turns **OFF**.

Optional:

- **a. ON/OFF** (Press the **LIGHT** button once, the Spa Light turns **ON**, press it again, the Spa Light turns **OFF**).
- **b.** Dimmable (There are five different steps to adjust brightness)
- Color LED (Available with J&J Electronics or Sloan or Rising Dragon junction box only)
- **6.** Press Function button, the Function turns **ON/OFF** or **ON** at low speed, ON at high speed, then **OFF**.



Default Timeout setting: Spa Light is 60 minutes; Blower is 15 minutes, Jet at low speed is 60 minutes; and Jet at high speed is 15 minutes. User can change these default times in DEVICE TIMEOUT setting menu.

PLEASE SEE ERROR SCREEN IDENTIFICATIONS ON THE REVERSE.






QUICK REFERENCE

NEO 2100, 1100 and 1000 Topside Panels

ERROR SCREENS



or replace SENSOR 2. Wait for water temperature to cool down. Check to be sure there is enough water flow through heater.


Error casued when SENSOR 1, 2, or 3 detects low temperature. All JETS and BLOWERS will turn JETS and BLOWERS will shut down when all 3 SENSORS reach a desired temperature.

> Check SENSOR 3 connection or replace SENSOR 3.

Check SENSOR 2 connection

Check SENSOR 3 connection.

Press RETURN to clear Sensor 2 open Press RETURN to clear Sensor 2 short **Press RETURN to clear** Sensor 3 open **Press RETURN to clear** Sensor 3 short



Press RETURN to clear

Heater Overheat

Press RETURN to clear

