




2 ½" STRAIGHT BODY POLY STORM GUNITE JET (210-3840) INSTALLATION INSTRUCTIONS AND PRESSURE TESTING




1. Hang Poly Storm Gunite Jet Body with ties through preset holes onto steel rebar.




2. Estimate needed length of 2 ½" PVC pipe by thickness of wall. Cut 2 ½" PVC pipe at least 4" longer than estimated finish length. Then glue 2 ½" PVC pipe into body.




3. Glue 2 ½" cap onto end of pipe for pressure test before guniting.




4. While guniting, scoop out gunite around the 2 ½" PVC pipe, allowing for the plaster niche (425-5030). Before plastering, cut the 2 ½" pipe so that the plastic niche will fit flush with the finished wall. Glue the plaster niche onto the pipe, then cover the niche with tape for plastering.




5. Cut a piece of 1" PVC pipe a couple of inches longer than the 2 ½" pipe and glue the threaded retainer ring to it.



6. Insert 1" PVC pipe assembly through the niche and up to the jet body assembly and thread in. Slide the Gunite Pipe Measuring Tool (218-1890A) over the end of the pipe until flush against the plaster niche.



7. Draw a reference line on the 1" PVC pipe, flush with the back edge of the measuring tool.




8. Remove the 1" pipe assembly from the jet body assembly and realign the measuring tool with the reference line. Make a new line at the Poly Storm Gunite Jet setback on the measuring tool.








2200 East Sturgis Road, Oxnard CA 93030 • Phone 805.981.0262 • Fax 805.981.9403

www.waterwayplastics.com • waterway@waterwayplastics.com





13. Always use at least one non-adjustable internal per spa to prevent deadheading pump.





To prevent personal injury, shock, or property/equipment damage, an Air Spring Check Valve (2" 600-8160, 1 1/2" 600-8140) must be installed on the blower stand pipe in case of a water backup in the air line.


NOTE: If a blower is not being used, please direct the air intake toward the ground using the 2" Sweep Vent Grate Assembly (400-4130) on the Air Inlet Pipe.




POLY STORM JET INTERNALS AND ACCESSORIES




Always use at least one Non-Adjustable internal per spa to prevent deadheading pump.




Large Volume
212-8040G - White
17-20 GPM




Galaxy
212-8190G - White
10 GPM




Galaxy Massage
212-8530G - White
10 GPM




Power Storm II
212-8250G - White
10 GPM




Multi Massage
212-8270G - White
10 GPM




Twin Roto
212-8120G - White
10 GPM




Roto
212-8010G - White
10 GPM




Directional
212-8050G - White
10 GPM



Massage (7 Nozzle)
212-8030G - White
10 GPM



Wrench
218-1890A



Handheld Jet
210-3250
10 GPM

WARRANTY

For product registration visit: www.waterwayplastics.com.

For Warranty questions or claims please contact point of purchase.