








SWIM SPA / SWIM INSTRUCTIONS

1. Touch the SWIM  icon to turn the Variable Speed Swim pumps ON – the SWIM icon on the LCD screen will turn yellow. 





2. Touch the **30%** PERCENT and swipe up or down to select the speed you want. Then touch SELECT. 





3. Touch the SWIM  icon again to turn OFF the pump – the yellow SWIM icon on the LCD screen will turn OFF. 






SWIM SPA / SWIM WORKOUT INSTRUCTIONS



1. Touch the SWIM WORKOUT  icon to turn the pumps ON – the SWIM WORKOUT icon on the LCD screen will turn orange. 

The Swim Workout cycle will run progressing through each of up to 10 pre-programmed cycles until it is complete, then it will turn OFF. 




2. To change the speed for just one mode while in use touch the PERCENT. **30%** Then swipe up or down to select the speed you want. Touch SELECT.  That speed will run for this preset only.



3. Touch SWIM WORKOUT  icon again to turn OFF the pumps – the SWIM WORKOUT icon on the LCD screen will turn OFF. 



SWIM SPA / SWIM WORKOUT PROGRAMMING



1. To program SWIM WORKOUT, swipe to the left.



Select the **TIMER** icon.




Swipe down.




Select **SWIM WORKOUT**.



2. Swipe up or down to select the PRESET #, DURATION and SPEED.



3. Select **SAVE** to save your settings.



4. Select **HOME** to return to the HOME screen and start your workout.



2200 East Sturgis Road, Oxnard CA 93030 • Phone 805.981.0262 • Fax 805.981.9403
 waterway@waterwayplastics.com • www.waterwayplastics.com

